


# Roof Mounting System Adjustable Hook Installation instructions



## GB | Use

Mounting system for installing framed PV modules with heights between 30 and 50 mm on pitched roofs with the following characteristics:

- Roof pitch 5° - 60° (solar fasteners), 20° - 60° (Roof hooks)
- Single and double roman, plain tile, natural slate, and flat tiles with wooden substructures.
- PV-panel landscape and portrait oriented

Static calculation must exist and be considered according to local regulations.

## Installation guidelines

Ensure that the roof construction is suitable for the introduction of forces at the fixing points and their subsequent transmission. In order to compensate thermal expansion, include a break every 12 meters when planning the PV-system. For module positioning/fastening points please refer to manufacturers recommendations. Please follow your local timber construction standard. Please do not use installed roof connections as ladder. If installation is located within 10km from the coast, we advise not to use zinc coated material. For further information please contact your sales representative or the technical department at Hopergy.

**The structural stability of the PV-system must be verified before installation. The building must be able to support the additional weight safely.**

## Installation notes

Please read these installation instructions carefully before starting the installation and familiarise yourself with the system components. During the installation and in particular whilst working on the roof, ensure to work according to the relevant health and safety guidelines, safety guidelines and please follow the current rules and regulations for your corresponding region.

The individual installation instructions are merely recommendations in accordance with the current state of technology and are based on previous experiences of how Hopergy systems can be installed.

If any special characteristics of the roof or object need to be taken into account, we recommend you to consult specialists such as roofers or structural engineers where necessary. Please check that the applied manual which is up to date. All manuals are available in the download area at [www.hopergy.com](http://www.hopergy.com)

## Testing/certification:

- TÜV
- MCS012 (IK0197)
- ISO 9001

## Applicable Documents

"General installation, maintenance and assembly instructions"

"Safety Instructions for Installation Instructions"

"Warranty and Disclaimer."


These documents are available at [www.hopergy.com](http://www.hopergy.com)

## Warranty:


The warranty only applies if an original and complete Hopergy system is used, with a layout designed by Hopergy.

Hopergy is not accountable for the roofs capability to maintain the introduced forces. Please check the roofs compatibility with a static engineer.


## TIN ROOF MOUNTING System




A




B



C



D





M8



13 mm







Solar Panels Layout



## Select 1 Hanger Screw System


Step.1 Remove or slide the tile from the roof girder slightly, and place the roof hook on the wooden rafter (refer to the picture below), Fix the roof hooks using two wooden screws. Grind tile as required and replace.



- A ST6.3\*80 Wooden screw
- C Spring Washer d8
- E M 8\*25 Carriage screws



- B M8 Hexagon Nuts
- D Plain Washer d8

**Hanger Screw installation completed. Double check ensure all Wooden screw be tighten**





**Step.2 Loosen the M8 bolt, then Push the rail into rail (Recommended Torque 12-14N.M)**

**① . Loosen the treasure block**




**② . Tighten the bolt**







## Installing the rail


**Step. 1** There are type for the SSC rail.( SSC rail Outer Joiner)





**OR** There are type for the SSC rail. ( Select Rail Joiner)




**Step. 2** Repeat the tile roof hook installation in accordance with the planned layout.



## Install Select panel clamps.







① . Against the panel, Hold it with your thumb



② . Against the panel, Hold it with your thumb


- Attention:**
- 1.The panel clamps close against the solar panel.
  - 2.Tighten the bolt slowly, until the clamp in holding position.
  - 3.Then use 12-14N.M torque to tighten the bolt.






**\*Ensure The Lock Nuts Are Secured to Rail.**

**\*Ensure The Lock Nuts Are Secured to Rail.**







**◎ Please install panels by row(vertical direction).**



**◎ When Solar panel installation completed. Double check ensure all bolts be tighten.**

**※ Note: The recommended order of Solar panel installation: from bottom to top, from left to right.**

## COMPONENTS

Part name	SSC Rail		
Part No.	RA-SSC-0000		
Figure			
Part name	Select Rails Joiner	SSC Rails Outer Joiner	
Part No.	SK-SSB	SK-SSC-01	
Figure			
Part name	15# Adjustable Hook & RCC		
Part No.	TRH-A15-RCC		
Figure			
Part name	End Clamp Kit	Inner Clamp Kit	
Part No.	PC-ECS00-NS1	PC-ICS00-NS1	
Figure	